

Preface

Copyright

This publication, including all photographs, illustrations and software, is protected under international copyright laws, with all rights reserved. Neither this manual, nor any of the material contained herein, may be reproduced without written consent of the author.

Version 1.0

Disclaimer

The information in this document is subject to change without notice. The manufacturer makes no representations or warranties with respect to the contents hereof and specifically disclaims any implied warranties of merchantability or fitness for any particular purpose. The manufacturer reserves the right to revise this publication and to make changes from time to time in the content hereof without obligation of the manufacturer to notify any person of such revision or changes.

Trademark Recognition

Microsoft, MS-DOS and Windows are registered trademarks of Microsoft Corp.

MMX, Pentium, Pentium-II, Pentium-III, Celeron are registered trademarks of Intel Corporation.

Other product names used in this manual are the properties of their respective owners and are acknowledged.

Federal Communications Commission (FCC)

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna
- Increase the separation between the equipment and the receiver
- Connect the equipment onto an outlet on a circuit different from that to which the receiver is connected
- Consult the dealer or an experienced radio/TV technician for help

Shielded interconnect cables and a shielded AC power cable must be employed with this equipment to ensure compliance with the pertinent RF emission limits governing this device. Changes or modifications not expressly approved by the system's manufacturer could void the user's authority to operate the equipment.

Declaration of Conformity

This device complies with part 15 of the FCC rules. Operation is subject to the following conditions:

- This device may not cause harmful interference.
- This device must accept any interference received, including interference that may cause undesired operation.

This device is in conformity with the following EC/EMC directives:

- ☐ **EN 55022** Limits and methods of measurement of radio disturbance characteristics of information technology equipment
- ☐ **EN 61000-3-2** Disturbances in supply systems caused
- ☐ **EN 61000-3-3** Disturbances in supply systems caused by household appliances and similar electrical equipment " Voltage fluctuations"
- ☐ **EN 55024** Information technology equipment-Immunity characteristics-Limits and methods of measurement
- ☐ **EN 60950** Safety for information technology equipment including electrical business equipment
- ☐ **CE marking**



Canadian Department of Communications

This class B digital apparatus meets all requirements of the Canadian Interference-causing Equipment Regulations.

Cet appareil numérique de la classe B respecte toutes les exigences du Règlement sur le matériel brouilleur du Canada.

About the Manual

The manual consists of the following:

- | | |
|---|---|
| Chapter 1
Introducing the Motherboard | Describes features of the ➞ page 1 motherboard. |
| Chapter 2
Installing the Motherboard | Describes installation of ➞ page 9 motherboard components. |
| Chapter 3
Using BIOS | Provides information on us- ➞ page 31 ing the BIOS Setup Utility. |
| Chapter 4
Using the Motherboard Software | Describes the motherboard ➞ page 69 software. |
| Chapter 5
ATI Crossfire™ Technology Support | Describes the ATI ➞ page 73 Crossfire™ Technology |
| Chapter 6
NVIDIA® Hybrid SLI® Technology Support | Provides information about ➞ page 77 SATA RAID Setup |

Chapter 7
Intel® Matrix Storage Manager
RAID Configurations

Describes Intel® Matrix Storage Manager RAID Configurations. ➡ page 81

Chapter 8
Trouble Shooting

Provides basic trouble shooting tips. ➡ page 87

Memo

TABLE OF CONTENTS

Preface	i
Chapter 1	1
Introducing the Motherboard	1
Introduction.....	1
Package Contents.....	1
Specifications.....	2
Motherboard Components.....	4
I/O Ports.....	6
Chapter 2	9
Installing the Motherboard	9
Safety Precautions.....	9
Installing the Motherboard in a Chassis.....	9
Checking Jumper Settings.....	10
Installing Hardware.....	11
<i>Installing the Processor.....</i>	<i>11</i>
<i>Installing the CPU Cooler.....</i>	<i>13</i>
<i>Installing Memory Modules.....</i>	<i>14</i>
<i>Installing Add-on Cards.....</i>	<i>16</i>
<i>Connecting Optional Devices.....</i>	<i>19</i>
<i>Installing a SATA Hard Drive.....</i>	<i>25</i>
Connecting Case Components.....	26
Chapter 3	31
Using BIOS	31
About the Setup Utility.....	31
<i>The Standard Configuration.....</i>	<i>31</i>
<i>Entering the Setup Utility.....</i>	<i>31</i>
<i>Resetting the Default CMOS Values.....</i>	<i>32</i>
Using BIOS.....	32
<i>BIOS Navigation Keys.....</i>	<i>33</i>
<i>Main Menu.....</i>	<i>34</i>
<i>Advanced Menu.....</i>	<i>35</i>
<i>Chipset Menu.....</i>	<i>47</i>
<i>M.I.B.X (MB Intelligent Bios X) Menu.....</i>	<i>54</i>
<i>Boot Menu.....</i>	<i>59</i>
<i>Security Menu.....</i>	<i>64</i>
<i>Exit Menu.....</i>	<i>65</i>
<i>Updating the BIOS.....</i>	<i>67</i>

Chapter 4	69
Using the Motherboard Software	69
Auto-installing under Windows XP/Vista/7.....	69
<i>Running Setup</i>	69
Manual Installation.....	71
ECS Utility Software (Intelligent EZ Utility).....	71
 Chapter 5	 73
ATI CrossFire™ Technology Support	73
Requirements.....	73
Installing CrossFire™ graphics cards.....	73
The Catalyst™ Control Center Dialog Box.....	75
<i>To Enable CrossFire™</i>	75
 Chapter 6	 77
NVIDIA® Hybrid SLI® Technology Support	77
Requirements.....	77
Installing your NVIDIA® SLI-Ready Components.....	77
Enabling NVIDIA® SLI.....	79
 Chapter 7	 81
Intel® Matrix Storage Manager RAID Configuration	81
Before creating a RAID set.....	81
Entering Intel® Matrix Storage Manager RAID BIOS utility.....	82
Creating a RAID set.....	83
Deleting a RAID set.....	85
Resetting disks to Non-RAID.....	86
Exiting Setup.....	86
 Chapter 8	 87
Trouble Shooting	87
Start up problems during assembly.....	87
Start up problems after prolong use.....	88
Maintenance and care tips.....	88
Basic Troubleshooting Flowchart.....	89
Post Code Checkpoints	91

Chapter 1

Introducing the Motherboard

Introduction

Thank you for choosing the **Z77H2-A2X** motherboard. This motherboard is a high performance, enhanced function motherboard designed to support the LGA1155 socket for latest 3rd Generation Intel Core™ i7/ i5/ i3/ Pentium/ Celeron Processors.

This motherboard is based on Intel® Z77 Express Chipset for best desktop platform solution. It supports up to 32 GB of system memory with dual channel DDR3 2667(OC)+/1600/1333/1066 MHz. Two PCI Express x16 slots, intended for Graphics Interface, are fully conformed to PCI Express 3.0 Standard. In addition, two PCI Express x1 slots and two PCI slots are for extending usage.

It integrates USB 2.0 and USB 3.0 interface, supporting up to six USB 2.0 ports (four USB 2.0 ports at the rear panel and one USB 2.0 header supports additional two USB 2.0 ports) and six USB 3.0 ports (four USB 3.0 ports at the rear panel and one USB 3.0 header supports additional two USB 3.0 ports). The USB 2.0 header provides EZ charger technology, please refer to [Front Panel USB headers](#) of chapter 2 for more details.

The motherboard is equipped with advanced full set of I/O ports in the rear panel, including one D-sub (VGA) port, one DVI port, one HDMI port, one RJ45 LAN connector, one WIFI connector, one Bluetooth, one eSATA 2.0 connector, four USB 2.0 ports, four USB 3.0 ports and audio jacks for line-in, line-out and Optical SPDIF Out.

In addition, this motherboard supports four SATA 6.0Gb/s and two SATA 3.0Gb/s connectors for expansion.

Package Contents

Your motherboard package ships with the following items:

- ☐ Z77H2-A2X Motherboard
- ☐ Quick Installation Guide
- ☐ User Manual
- ☐ DVD
- ☐ I/O Shield
- ☐ 6 SATA 6.0Gb/s Cables
- ☐ 1 USB3.0 Front Panel
- ☐ 1 set USB CAP (6 pcs USB CAP in one package)
- ☐ 1 set VGA CAP (VGA/DVI/HDMI in one package)
- ☐ 1 SLI bridge

Specifications

CPU	<ul style="list-style-type: none"> LGA1155 socket for latest 3rd Generation Intel Core™ i7/ i5/ i3/ Pentium/ Celeron Processors DMI 5.0GT/s TDP: 125W <p><i>Note: Please go to ECS website for the latest CPU support list.</i></p>
Chipset	<ul style="list-style-type: none"> Intel® Z77 Chipset
Memory	<ul style="list-style-type: none"> Dual-channel DDR3 memory architecture 4 x 240-pin DDR3 DIMM sockets support up to 32 GB Supports DDR3 2667(OC)+/1600/1333/1066 MHz DDR3 SDRAM <p><i>Note1: Please go to ECS website for the latest Memory support list.</i></p> <p><i>Note2: DDR3_1 with DDR3_3 are the same channel, DDR_2 with DDR_4 are the same channel by Intel Specifications.</i></p>
Expansion Slots	<ul style="list-style-type: none"> 2 x PCI Express x16 Gen3.0 slots 2 x PCI Express x1 slots 2 x PCI slots 1 x Mini PCI Express x 1 slot <ul style="list-style-type: none"> - Supports Mini SATA - Supports Mini PCI Express <p><i>Note: When using two VGA cards, the bandwidth is @8 bandwidth, when using one VGA card, the bandwidth is @16.</i></p>
Storage	<ul style="list-style-type: none"> Supported by Intel® Z77 <ul style="list-style-type: none"> - 2 x Serial ATA 3.0Gb/s devices (SATA2 1/2) - 2 x Serial ATA 6.0Gb/s devices (SATA3 3/4) - RAID0, RAID1, RAID5, RAID10 Configuration Supported by Asmedia ASM1061 <ul style="list-style-type: none"> - 2 x Serial ATA 6.0Gb/s devices (SATA3 5/6)
Audio	<ul style="list-style-type: none"> Realtek ALC892 8-Ch High Definition audio CODEC - Compliant with HD audio specification
LAN	<ul style="list-style-type: none"> Realtek RTL 8111E Gigabit Lan
Rear Panel I/O	<ul style="list-style-type: none"> 4 x USB 3.0 ports 4 x USB 2.0 ports 1 x D-sub (VGA) port 1 x HDMI port 1 x DVI port 1 x RJ45 LAN connector 1 x Audio port (1 x line in, 4 x line out, 1 x Optical SPDIF Out) 1 x Wireless Lan Dongle 1 x Bluetooth Dongle 1 x eSATA 3Gb/s port

Internal I/O Connectors & Headers	<ul style="list-style-type: none"> • 1 x 24-pin ATX Power supply connector • 1 x 8-pin ATX Power supply connector • 1 x 4-pin CPU_FAN connector • 1 x 3-pin SYS_FAN connector • 1 x 3-pin PWR_FAN connector • 1 x USB 2.0 header supports additional two USB 2.0 ports (F_USB supports EZ charger function) • 1 x USB 3.0 header supports additional two USB 3.0 ports (USB3F) • 2 x Serial SATA 3.0Gb/s connectors (SATA2 1/2) • 4 x Serial SATA 6.0Gb/s connectors (SATA3 3/4/5/6) • 1 x COM header • 1 x Clear CMOS jumper • 1 x Case open header • 1 x Buzzer • 1 x SPDIF out header • 1 x Front Panel switch/LED header • 1 x Front Panel audio header • 1 x Debug post LED • 1 x power on button • 1 x Reset button
System BIOS	<ul style="list-style-type: none"> • AMI BIOS with 64Mb SPI Flash ROM <ul style="list-style-type: none"> - Supports ECS M.I.B X Utility - Supports Plug and Play - Supports ACPI & DMI - Supports S1 / STR (S3) /STD (S4) - Supports Hardware monitor - Audio, LAN, can be disabled in BIOS - F7 hot key for boot up devices option - Supports CPU/Memory/GPU - Supports Dual Display - Supports GUI UEFI (Advantage mode) - Supports Multi-Language
AP Support	<ul style="list-style-type: none"> • Supports eBLU/eOC/eDLU/eSF/EZ Charger <p><i>Note: Please go to ECS website to get the latest news for AP supporting.</i></p>
Form Factor	<ul style="list-style-type: none"> • ATX Size, 305mm x 244mm

Motherboard Components





Table of Motherboard Components

LABEL	COMPONENTS
1. CPU Socket	LGA1155 socket for latest 3 rd Generation Intel Core™ i7/ i5/ i3/ Pentium/ Celeron Processors
2. CPU_FAN	4-pin CPU cooling fan connector
3. DDR3_1~4	240-pin DDR3 Module slots
4. PWR_FAN	3-pin power cooling fan connector
5. ATX_POWER	Standard 24-pin ATX power connector
6. RST_BTN	Reset Switch
7. PWR_BTN	Power on Switch
8. SATA3 3~6	Serial ATA 6.0 Gb/s connectors
9. SATA2 1~2	Serial ATA 3.0 Gb/s connectors
10. POST	POST Error Code LED
11. MINIPCIIE	Mini-PCI Express x1 slot
12. ME_UNCLOCK	ME Unlock header-for factory use only
13. F_PANEL	Front panel switch/LED header
14. USB3F	Front panel USB 3.0 header
15. CASE	Case open header
16. F_USB	Front panel USB 2.0 header (supports EZ Charger)
17. SPI_DEBUG	SPI Debug header-for factory use only
18. CLR_CMOS	Clear CMOS jumper
19. SYS_FAN	3-pin system cooling fan connector
20. COM	Onboard serial port header
21. SPDIFO	SPDIF out header
22. F_AUDIO	Front panel audio header
23. PCI1~2	32-bit add-on card slots
24. PCIEX16/PCIEX16_S	PCI Express slots for graphics interface
25. PCIE1~2	PCI Express x1 slots
26. ATX12V	8-pin +12V power connector

I/O Ports



1. Bluetooth Dongle

Use this port to transfer data between your computer and other devices which support bluetooth function.

2. VGA Port

Connect your monitor to the VGA port.

3. Wireless LAN Dongle

Use this port to receive wireless signal.


4. USB 3.0 Ports

Use the USB 3.0 ports to connect USB 3.0 devices.

5. LAN Port

Connect an RJ-45 jack to the LAN port to connect your computer to the Network.

LAN LED	Status	Description
Activity LED	OFF	No data
	Orange blinking	Active
Link LED	OFF	No link
	Green	Link



6. Audio Ports

Use the audio jack to connect audio devices. The C port is for stereo line-in signal, while the E port is for microphone in signal. This motherboard supports audio devices that correspond to the A, B, and D port respectively. In addition, both of the 2 ports, B, and D provide user with both right & left channels individually. Users please refer to the following note for specific port function definition.

A: Center & Woofer	D: Front Out
B: Back Surround	E: Mic. in Rear
C: Line-in	-



The above port definition can be changed to audio input or audio output by changing the driver utility setting.

7. Optical SPDIF Output

This jack connects to external optical digital audio output devices.

8. HDMI Port

You can connect the display device to the HDMI port.

9. USB 2.0 Ports

Use the USB 2.0 ports to connect USB 2.0 devices.

10. eSATA 3Gb/s Ports

Use this port to connect to external SATA boxes or Serial ATA port multipliers.

11. DVI Port

Connect the DVI port to the monitor.

Chapter 2

Installing the Motherboard


2-1. Safety Precautions

Follow these safety precautions when installing the motherboard:

- Wear a grounding strap attached to a grounded device to avoid damage from static electricity.
- Discharge static electricity by touching the metal case of a safely grounded object before working on the motherboard.
- Leave components in the static-proof bags.
- Always remove the AC power by unplugging the power cord from the power outlet before installing or removing the motherboard or other hardware components.

2-2. Installing the motherboard in a Chassis


This motherboard carries a ATX form factor of 305 x 244 mm. Choose a chassis that accommodates this form factor. Make sure that the I/O template in the chassis matches the I/O ports installed on the rear edge of the motherboard. Most system chassis have mounting brackets installed in the chassis, which corresponds to the holes in the motherboard. Place the motherboard over the mounting brackets and secure the motherboard onto the mounting brackets with screws.



Do not over-tighten the screws as this can stress the motherboard.

2-3. Checking Jumper Settings

The following illustration shows the location of the motherboard jumpers. Pin 1 is labeled.



To avoid the system instability after clearing CMOS, we recommend users to enter the main BIOS setting page to “Load Default Settings” and then “Save and Exit Setup”.

2-4. Installing Hardware


2-4-1. Installing the Processor

- This motherboard has an LGA1155 socket.
- When choosing a processor, consider the performance requirements of the system. Performance is based on the processor design, the clock speed and system bus frequency of the processor, and the quantity of internal cache memory and external cache memory.
- You may be able to change the settings in the system Setup Utility. We strongly recommend you do not over-clock processor or other components to run faster than their rated speed.
- The following illustration shows CPU installation components.


A. Press the hook of lever down with your thumb and pull it to the right side to release it from retention tab.




B. Lift the tail of the load lever and rotate the load plate to fully open position.



C. Grasp the edge of the package substrate. Make sure pin 1 indicator is on your bottom-left side. Aim at the socket and place the package carefully into the socket by purely vertical motion.



D. Rotate the load plate onto the package IHS (Intergraded Heat Spreader). Engage the load lever while pressing down lightly onto the load plate. Secure the load lever with the hook under retention tab. Then the cover will flick automatically.




Please save and replace the cover onto the CPU socket if processor is removed.


2-4-2. Installing the CPU Cooler

- Install the cooling fan in a well-lit work area so that you can clearly see the motherboard and processor socket.
- Avoid using cooling fans with sharp edges in case the fan casing and the clips cause serious damage to the motherboard or its components.
- To achieve better airflow rates and heat dissipation, we suggest that you use a high quality fan with 3800 rpm at least. CPU fan and heat sink installation procedures may vary with the type of CPU fan/heat sink supplied. The form and size of fan/heat sink may also vary.
- DO NOT remove the CPU cap from the socket before installing a CPU.
- Return Material Authorization (RMA) requests will be accepted only if the motherboard comes with the cap on the LGA1155 socket.
- The following illustration shows how to install CPU fan.


A. Apply some thermal grease onto the contacted area between the heatsink and the CPU, and make it to be a thin layer.



B. Fasten the cooling fan supporting base onto the CPU socket on the motherboard. And make sure the CPU fan is plugged to the CPU fan connector.




C. Connect the CPU cooler power connector to the CPU_FAN connector.




2-4-3. Installing Memory Modules


- This motherboard accommodates two memory modules. It can support two 240-pin DDR3 2667(OC)+/1600/1333/1066.
- Do not remove any memory module from its antistatic packaging until you are ready to install it on the motherboard. Handle the modules only by their edges. Do not touch the components or metal parts. Always wear a grounding strap when you handle the modules.
- You must install at least one module in any of the four slots. Total memory capacity is 32 GB.
- Refer to the following to install the memory modules.
 - A. Push the latches on each side of the DIMM slot down.



- B. Install the DIMM module into the slot and press it firmly down until it seats correctly. Check that the cutouts on the DIMM module edge connector match the notches in the DIMM slot.



- C. The slot latches are levered upwards and latch on to the edges of the DIMM.



- The four DDR3 memory sockets (DDR3_1, DDR3_2, DDR3_3 and DDR3_4) are divided into two channels and each channel has two memory sockets as following:

▶▶ Channel A: DDR3_1, DDR3_2

▶▶ Channel B: DDR3_3, DDR3_4

Recommend memory configuration


Mode	Sockets			
	DDR3_1	DDR3_2	DDR3_3	DDR3_4
1 DIMM		Populated		
2 DIMMs		Populated		Populated
3 DIMMs		Populated	Populated	Populated
4 DIMMs	Populated	Populated	Populated	Populated



We suggest users not mix memory type. It is recommended to use the same brand and type memory on this motherboard.

2-4-4. Installing Add-on Cards

The slots on this motherboard are designed to hold expansion cards and connect them to the system bus. Expansion slots are a means of adding or enhancing the motherboard's features and capabilities. With these efficient facilities, you can increase the motherboard's capabilities by adding hardware that performs tasks that are not part of the basic system.



PCI16X /PCI16X_S Slot

The PCI Express x16 slots are used to install external PCI Express graphics cards that are fully compliant to the PCI Express Base Specification revision 3.0.

PCI1~2 Slots

This motherboard is equipped with two standard PCI slots. PCI stands for Peripheral Component Interconnect and is a bus standard for expansion cards, which for the most part, is a supplement of the older ISA bus standard. The PCI slots on this board are PCI v3.0 compliant.

PCI1~2 Slots

The PCI Express x1 slots are fully compliant to the PCI Express Base Specification revision 2.0.

MINIPCI Slot

The Mini PCI Express x1 slot is for extending usage, such as wireless card or TV card.



Before installing an add-on card, check the documentation for the card carefully. If the card is not Plug and Play, you may have to manually configure the card before installation.

PCIEX16 slot speed

Mode	Slots	
	PCIEX16	PCIEX16_S
2 cards	run at X16	
	run at X8	run at X8

Follow these instructions to install an add-on card:


- 1 Remove a blanking plate from the system case corresponding to the slot you are going to use.
- 2 Install the edge connector of the add-on card into the expansion slot. Ensure that the edge connector is correctly seated in the slot.
- 3 Secure the metal bracket of the card to the system case with a screw.




1. For some add-on cards, for example graphics adapters and network adapters, you have to install drivers and software before you can begin using the add-on card.

2. The onboard PCI interface does not support 64-bit SCSI cards.


Please refer the following illustrations to install the add-on card:



Install the VGA Card in the PCI slot




Install the VGA Card in the PCIe X1 slot




Install the VGA Card in the PCIe X16 slot

Follow these instructions to install a wireless card:


- 1 Remove a blanking plate from the system case, and insert the wireless card into the MINIPCI slot rightwards, then tighten the two screws (Please refer to Picture 1).
- 2 Press the metal connector of the cable into the connector on the wireless card. Ensure that the metal connector is correctly seated (Please refer to Picture 2).
- 3 Make the other end of the cable (with a gold screw) through the upper hole of the bracket, and tighten the antenna on to the gold screw after installing a metal gasket on the screw (Please refer to Picture 3).



Picture 1




Picture 2



Picture 3

2-4-5. Connecting Optional Devices


Refer to the following for information on connecting the motherboard's optional devices:




No.	Components	No.	Components
1	SATA1~6	5	F_USB
2	ME_UNLOCK	6	COM
3	USB3F	7	SPDIFO
4	CASE	8	F_AUDIO

1. SATA1~6: Serial ATA connectors

SATA3 3~6 connectors are used to support the Serial ATA 3.0Gb/s device, SATA2 1/2 connectors support the Serial ATA 6.0Gb/s device. Simpler disk drive cabling and easier PC assembly. It eliminates limitations of the current Parallel ATA interface. But maintains register compatibility and software compatibility with Parallel ATA.




2. ME_UNLOCK: ME Unlock Header



3. USB3F: Front Panel USB 3.0 header


This Motherboard implements one USB 3.0 header supporting 2 extra front USB 3.0 ports, which delivers 5Gb/s transfer rate.



Please make sure that the USB cable has the same pin assignment as indicated above. A different pin assignment may cause damage or system hang-up.

4. CASE: Chassis Intrusion Detect Header


This detects if the chassis cover has been removed. This function needs a chassis equipped with intrusion detection switch and needs to be enabled in BIOS.



5. F_USB: Front Panel USB 2.0 headers (supports EZ Charger)

The motherboard has one USB 2.0 header supporting two USB 2.0 ports. Additionally, some computer cases have USB ports at the front of the case. If you have this kind of case, use auxiliary USB connector to connect the front-mounted ports to the motherboard.


F_USB supports EZ Charger technology, provides 3 times current than general USB port in off mode for USB devices. It is useful and excellent, especially for the iPhone, iPad and iPod touch devices that need a large amount of current for faster recharging within less time.



Please make sure that the USB cable has the same pin assignment as indicated above. A different pin assignment may cause damage or system hang-up.


6. COM: Onboard serial port header

Connect a serial port extension bracket to this header to add a serial port to your system.




7. SPDIFO: SPDIF out header

This is an optional header that provides an SPDIFO (Sony/Philips Digital Interface) output to digital multimedia device through optical fiber or coaxial connector.




8. F_AUDIO: Front Panel Audio Header

The front panel audio header allows the user to install auxiliary front-oriented microphone and line-out ports for easier access. This header supports HD audio by default. If you want connect an AC' 97 front panel audio to HD onboard headers, please set as below picture.



AC' 97 Audio Configuration: To enable the front panel audio connector to support AC97 Audio mode.

If you use AC' 97 Front Panel, please tick off the option of "Disabled Front Panel Detect ". If you use HD Audio Front Panel, please don't tick off "Disabled Front Panel Detect ".



** For reference only*

If you use AC' 97 Front Panel, please don't tick off "Using Front Jack Detect ". If you use HD Audio Front Panel, please tick off the option of "Using Front Jack Detect ".



** For reference only*

2-4-6. Installing a SATA Hard Drive

This section describes how to install a SATA Hard Drive.

About SATA Connectors


Your motherboard features six SATA connectors supporting a total of six drives. SATA refers to Serial ATA (Advanced Technology Attachment) is the standard interface for the IDE hard drives which are currently used in most PCs. These connectors are well designed and will only fit in one orientation. Locate the SATA connectors on the motherboard and follow the illustration below to install the SATA hard drives.

Installing Serial ATA Hard Drives

To install the Serial ATA (SATA) hard drives, use the SATA cable that supports the Serial ATA protocol. This SATA cable comes with a SATA power cable. You can connect either end of the SATA cable to the SATA hard drive or the connector on the motherboard.

Refer to the illustration below for proper installation:


- 1 Attach either cable end to the connector on the motherboard.
- 2 Attach the other cable end to the SATA hard drive.
- 3 Attach the SATA power cable to the SATA hard drive and connect the other



** For reference only*

2-4-7. Connecting Case Components

After you have installed the motherboard into a case, you can begin connecting the motherboard components. Refer to the following:




No.	Components
1	CPU_FAN
2	PWR_FAN
3	ATX_POWER
4	F_PANEL
5	SYS_FAN
6	ATX_12V

1 & 2 & 5. CPU_FAN (CPU cooling FAN Power Connector) & SYS_FAN (System Cooling FAN Power Connector) & PWR_FAN (FAN Power Connector)

Connect the CPU cooling fan cable to **CPU_FAN**.

Connect the system cooling fan connector to **SYS_FAN**.

Connect the system cooling fan connector to **PWR_FAN**.




Users please note that the fan connector supports the CPU cooling fan of 1.1A ~ 2.2A (26.4W max) at +12V.

3 & 6. ATX_POWER (ATX 24-pin Power Connector) & ATX12V (ATX 12V Power Connector)


Connect the standard power supply connector to **ATX_POWER**.

Connect the auxiliary case power supply connector to **ATX12V**.



Connecting 24-pin power cable

The ATX 24-pin connector allows you to connect to ATX v2.x power supply.




24-pin power cable

With ATX v2.x power supply, users please note that when installing 24-pin power cable, the latches of power cable and the ATX match perfectly.



Connecting 8-pin power cable

The ATX12V8P power connector is used to provide power to the CPU.




8-pin power cable

When installing 8-pin power cable, the latches of power cable and the ATX12V8P match perfectly.



Connecting 4-pin power cable

The ATX12V8P power connector is used to provide power to the CPU.




4-pin power cable

When installing 4-pin power cable, the latches of power cable and the ATX12V8P match perfectly.

4. Front Panel Header

The front panel header (F_PANEL) provides a standard set of switch and LED headers commonly found on ATX or Micro ATX cases. Refer to the table below for information:



Hard Drive Activity LED

Connecting pins 1 and 3 to a front panel mounted LED provides visual indication that data is being read from or written to the hard drive. For the LED to function properly, an IDE drive should be connected to the onboard IDE interface. The LED will also show activity for devices connected to the SCSI (hard drive activity LED) connector.

Power/Sleep/Message waiting LED

Connecting pins 2 and 4 to a single or dual-color, front panel mounted LED provides power on/off, sleep, and message waiting indication.

Reset Switch

Supporting the reset function requires connecting pin 5 and 7 to a momentary-contact switch that is normally open. When the switch is closed, the board resets and runs POST.

Power Switch

Supporting the power on/off function requires connecting pins 6 and 8 to a momentary-contact switch that is normally open. The switch should maintain contact for at least 50 ms to signal the power supply to switch on or off. The time requirement is due to internal de-bounce circuitry. After receiving a power on/off signal, at least two seconds elapses before the power supply recognizes another on/off signal.

This concludes Chapter 2. The next chapter covers the BIOS.

Chapter 3

Using BIOS

About the Setup Utility

The computer uses the latest “American Megatrends Inc. ” BIOS with support for Windows Plug and Play. The CMOS chip on the motherboard contains the ROM setup instructions for configuring the motherboard BIOS.

The BIOS (Basic Input and Output System) Setup Utility displays the system’s configuration status and provides you with options to set system parameters. The parameters are stored in battery-backed-up CMOS RAM that saves this information when the power is turned off. When the system is turned back on, the system is configured with the values you stored in CMOS.

The BIOS Setup Utility enables you to configure:

- Hard drives, diskette drives and peripherals
- Video display type and display options
- Password protection from unauthorized use
- Power Management features

The settings made in the Setup Utility affect how the computer performs. Before using the Setup Utility, ensure that you understand the Setup Utility options.

This chapter provides explanations for Setup Utility options.

The Standard Configuration

A standard configuration has already been set in the Setup Utility. However, we recommend that you read this chapter in case you need to make any changes in the future.

This Setup Utility should be used:


- when changing the system configuration
- when a configuration error is detected and you are prompted to make changes to the Setup Utility
- when trying to resolve IRQ conflicts
- when making changes to the Power Management configuration
- when changing the password or making other changes to the Security Setup

Entering the Setup Utility

When you power on the system, BIOS enters the Power-On Self Test (POST) routines. POST is a series of built-in diagnostics performed by the BIOS. After the POST routines are completed, the following message appears:

Press DEL to enter SETUP

Press the delete key to access BIOS Setup Utility.



Resetting the Default CMOS Values

When powering on for the first time, the POST screen may show a “CMOS Settings Wrong” message. This standard message will appear following a clear CMOS data at factory by the manufacturer. You simply need to Load Default Settings to reset the default CMOS values.


Note: Changes to system hardware such as different CPU, memories, etc. may also trigger this message.




Using BIOS

When you start the Setup Utility, the main menu appears. The main menu of the Setup Utility displays a list of the options that are available. A highlight indicates which option is currently selected. Use the cursor arrow keys to move the highlight to other options. When an option is highlighted, execute the option by pressing <Enter>.

Some options lead to pop-up dialog boxes that prompt you to verify that you wish to execute that option. Other options lead to dialog boxes that prompt you for information.

Some options (marked with a icon ) lead to submenus that enable you to change the values for the option. Use the cursor arrow keys to scroll through the items in the submenu.

In this manual, default values are enclosed in parenthesis. Submenu items are denoted by a icon .



The default BIOS setting for this motherboard apply for most conditions with optimum performance. We do not suggest users change the default values in the BIOS setup and take no responsibility to any damage caused by changing the BIOS settings.

BIOS Navigation Keys

The BIOS navigation keys are listed below:

ESC	Exits the current menu
↑↓→←	Scrolls through the items on a menu
+/-	Change Opt.
Enter	Select
F1	General Help
F2	Previous Value
F3	Optimized Defaults
F4	Save & Exit




1. For the purpose of better product maintenance, the manufacture reserves the right to change the BIOS items presented in this manual. The BIOS setup screens shown in this chapter are for reference only and may differ from the actual BIOS. Please visit the manufacture's website for updated manual.

2. In this Gui BIOS, you can operate by mouse or keyboard. Click : select item; Double click: enter; Right click: exit.

Main Menu

This menu shows the information of BIOS and enables you to set the system language, date and time.



System Language (English)


This item is used to set system language.

Date & Time

The Date and Time items show the current date and time on the computer. If you are running a Windows OS, these items are automatically updated whenever you make

Advanced Menu

The Advanced menu items allow you to change the settings for the CPU and other system.



Launch PXE OpROM (Disabled)


The item enables or disables launch PXE Option ROM.

Launch Storage OpROM (Enabled)

Use this item to enable or disable the Storage OpROM.

■ LAN Configuration

The item in the menu shows the LAN-related information that the BIOS automatically detects.




Onboard LAN Controller (Enabled)

Use this item to enable or disable the Onboard LAN.

Press <Esc> to return to the Advanced Menu page.


PC Health Status

On motherboards support hardware monitoring, this item lets you monitor the parameters for critical voltages, temperatures and fan speeds.



Smart Fan Function

Scroll to this item and press <Enter> to view the following screen:



CPU/System Smart Fan Control (Enabled)

This item enables you to define the CPU/system by smartly adjusting the CPU/system Fan. When it is set at certain temperature, the CPU/system Fan PWM value will change accordingly.

Smart Fan Mode (Normal)

This item allows you to select the fan mode (Normal, Quiet, Silent, or Manual) for a better operation environment. If you choose Normal mode, the fan speed will be auto adjusted depending on the CPU temperature. If you choose Quiet mode, the fan speed will be auto minimized for quiet environment. If you choose Silent mode, the fan speed will be auto restricted to make system more quietly. If you choose Manual mode, the fan speed will be adjust depending on users' parameters.

Smart Fan start PWM value (180)

This item is used to set the start PWM value of the smart fan.

Smart Fan start PWM TEMP(-) (30)

This item is used to set the start temperature of the smart fan.

DeltaT (3)

This item specifies the range that controls CPU temperature and keeps it from going so high or so low when smart fan works.

Smart Fan Slope PWM value (10 PWM value / unite)

This item is used to set the Slope Select PWM of the smart fan.

CPU Fan Full Speed Offset(-) (23)

This item is used to set the CPU fan full speed offset value.

Press <Esc> to return to the PC Health Status page.

System Component Characteristics


These items display the monitoring of the overall inboard hardware health events, such as System temperature, CPU & DIMM voltage, CPU & System fan speed... etc.

- CPU Fan Speed
- System Fan Speed
- PWR Fan Speed
- CPU Voltage
- AXG Voltage
- IMC Voltage
- DIMM Voltage
- PCH Voltage

Press <Esc> to return to the Advanced Menu page.

■ Power Management Setup

This page sets up some parameters for system power management operation.



Resume By RING (Disabled)

An input signal on the serial Ring Indicator (RI) line (in other words, an incoming call on the modem) awakens the system from a soft off state.

Resume By PME (Disabled)

The system can be turned off with a software command. If you enable this item, the system can automatically resume if there is an incoming call on the PCI Modem or PCI LAN card. You must use an ATX power supply in order to use this feature. Use this item to do wake-up action if inserting the PCI card.

Resume By USB (S3) (Disabled)

This item allows you to enable/disable the USB device wakeup function from S3 mode.

EUP Function (Enabled)

This item allows user to enable or disable EUP support.


Power LED Type (Dual Color LED)

This item shows the type of the Power LED.

Press <Esc> to return to the Advanced Menu page.

■ ACPI Configuration

The item in the menu shows the highest ACPI sleep state when the system enters suspend.




ACPI Sleep State [S3(Suspend to RAM)]

This item allows user to enter the ACPI S3 (Suspend to RAM) Sleep State(default).

Press <Esc> to return to the Advanced Menu page.

■ CPU Configuration

The item in the menu shows the CPU.



Intel(R) Celeron(R) CPU G440 @ 1.60GHz

This is display-only field and displays the information of the CPU installed in your computer.

EMT64 (Supported)

This item shows the computer supports EMT64.

Processor Speed (1600MHz)

This item shows the current processor speed.

Processor Stepping (206a7)

This item shows the processor stepping version.

Microcode Revision (25)

This item shows the Microcode version.

Processor Cores (1)

This item shows the core number of the processor.

Intel HT Technology (Not Supported)

This item shows that the computer does not support Intel HT Technology.

Intel VT-x Technology (Supported)

This item shows the computer supports Intel VT-x Technology.

Limit CPUID Maximum (Disabled)

Use this item to enable or disable the maximum CPUID value limit. When supports Prescott and LGA775 CPUs, enables this to prevent the system from “rebooting” when trying to install Windows NT 4.0.

Excute Disable Bit (Enabled)

This item allows the processor to classify areas in memory by where application code can execute and where it cannot. When a malicious worm attempts to insert code in the buffer, the processor disables code execution, preventing damage or worm propagation. Replacing older computers with Execute Disable Bit enabled systems can halt worm attacks, reducing the need for virus related repair.

CPU C3 Report

Use this item to enable or disable CPU C3 (ACPI C2) report to OS.

CPU C6 Report

Use this item to enable or disable CPU C6 (ACPI C3) report to OS.

Intel Virtualization Technology (Enabled)

When disabled, a VMM cannot utilize the additional hardware capabilities provided by Vondor Pool Technology.


Enhanced Halt (C1E) (Enabled)

Use this item to enable the CPU energy-saving function when the system is not running.

Press <Esc> to return to the Advanced Menu page.

■ SATA Configuration

Use this item to show the mode of serial SATA configuration options.



SATA Mode (IDE Mode)

Use this item to select SATA mode.

ON Chip eSATA/SATA 6Gb/s Controller Mode (AHCI Mode)

Use these items to select eSATA/SATA 6Gb/s Controller Mode.


SATA Port1~6/mSATA (Not Present)

This motherboard supports six SATA channels and one mSATA, each channel allows one SATA device to be installed. Use these items to configure each device on the SATA/mSATA channel.

Press <Esc> to return to the Advanced Menu page.

USB Configuration

Use this item to show the information of USB configuration.



All USB Devices (Enabled)

Use this item to enable or disable all USB devices.

Legacy USB Support (Enabled)

Use this item to enable or disable support for legacy USB devices. Setting to Audio allows the system to detect the presence of the USB device at startup. If detected, the USB controller legacy mode is enabled. If no USB device is detected, the legacy USB support is disabled.

Bluetooth (Enabled)

Use this item to enable or disable bluetooth function.


Wi-Fi (Enabled)

Use this item to enable or disable wireless LAN function.

Press <Esc> to return to the Advanced Menu page.

❑ Super IO Configuration

Use this item to show the information of Super IO configuration.




Super IO Chip (IT8728)

This item shows the information of the super IO chip.

❑ Serial Port 0 Configuration

Scroll to this item and press <Enter> to view the following screen:



Serial Port (Enabled)

This item allows you to enable or disable serial port.

Device Settings (IO=3F8h; IRQ=4)

This item shows the information of the device settings.

Change Settings (Auto)

Use this item to change device settings.

Press <Esc> to return to the Super IO Configuration page.


Temp. to 80-Port (Disable)

Use this item to enable or disable Temperature output 80-Port.

Press <Esc> to return to the Advanced Menu page.

Intel(R) Rapid Start Technology

Use this item to show the information of trusted computing configuration.




Intel(R) Rapid Start Technology (Disabled)

Use this item to enable or disable the Intel(R) Rapid Start Technology.


Chipset Menu

The chipset menu items allow you to change the settings for the North chipset, South chipset and other system.



System Agent Configuration

Scroll to this item and press <Enter> and view the following screen:



Initiate Graphic Adapter (Auto)

This item allows you to select graphics controller to use as the primary boot device.

IGD Memory (64M)

This item shows the information of the IGD (Internal Graphics Device) memory.

DVMT Memory (256M)

When set to Fixed Mode, the graphics driver will reserve a fixed position of the system memory as graphics memory, according to system and graphics requirements.

IGD Multi-Monitor (Disabled)


This item enables or disables IGD (Internal Graphics devices) multi-monitor.

Press <Esc> to return to the Chipset Menu page.

Multi-Monitor technology


Multi-Monitor technology can help you to increase the area available for programs running on a single computer system through using multiple display devices.

It is not only to increase larger screen viewing but also to improving personal productivity.




Please note that Multi-Monitor technology supports up to four monitors: one or two Intel integrated Graphics and one or two PCI-Express graphics devices under Windows 7.


Step 1. Insert ECS drives DVD to run Auto setup or browse the DVD to install Intel chipset drivers, VGA and sound drivers. (If you want know the detail information, please refer to chapter 4.)



Step 2. Install all the drivers of PCI-Express graphic cards. Click the Browse CD item, then appears the following screen. Select the driver you want to install(e.g NVIDIA GeForce 8400 GS(Microsoft Corporation-WDDM v1.1)) and double click it.




Step 3. Enable IGD Multi-Monitor from BIOS. In the following BIOS screen, please set IGD Multi-Monitor to [Enabled].






Step 4. Change the appearance of your displays under Windows 7.

1. Enter the Control Panel menu, select the Display in the All Control Panel Items and click the Screen Resolution, then appears the following screen.




2. Select display devices, set the multiple displays option and to extend desktop for display "Multi-Monitor technology".





■ PCH Configuration

Scroll to this item and press <Enter> to view the following screen:



Restore AC Power Loss (Power Off)

This item enables your computer to automatically restart or return to its operating status.

Audio Configuration

This item shows the information of the audio configuration.

Azalia HD Audio (Enabled)

This item enables or disables Azalia HD audio.

Azalia Internal HDMI codec (Enabled)

This item enables or disables Azalia Internal HDMI codec.

Case Open Warning (Disabled)

This item enables or disables the warning if the case is opened up, and the item below indicates the current status of the case.


Chassis Opened (No)

This item indicates whether the case has been opened.

Press <Esc> to return to the Chipset Menu page.

ME Configuration

Scroll to this item and press <Enter> to view the following screen:




ME FW Version (8.0.0.1351)

This item shows the ME FW version.

Press <Esc> to return to the Chipset Menu page.


M.I.B X (MB Intelligent BIOS X) Menu

This page enables you to set the clock speed and system bus for your system. The clock speed and system bus are determined by the kind of processor you have installed in your system.



▶ CPU OverClocking Configuration

Scroll to this item to view the following screen:



CPU Frequency(1/100 MHz) (10000)

This item shows the information of CPU frequency.

CPU Ratio (23)

This item allows users to control non turbo CPU ratio.

Enhanced Intel SpeedStep Technology (Enabled)

This item allows users to enable or disable the EIST (Enhanced Intel SpeedStep Technology).

Turbo Mode (Enabled)

This item allows you to control the Intel Turbo Boost Technology.

Runtime Turbo Enable (Disabled)

This item shows if CPU support runtime turbo or not.

OverClocking Extra Vol.(1/256V) (0)

Use this item to set over clocking extra voltage.

IA Core Current Max(1/8 Amp) (1680)

Use this item to control CPU Current Limit.

iGFX Core Current Max(1/8 Amp) (800)

Use this item to control iGFX Core Current Limit.

Long Duration Power Limit Override (1440)

Intel(R) Turbo Boost Technology will use this power limit during the long duration power limit time window.

Long Duration Maintained (10)

Use this item to control the time window over PL1 value should be maintained. This is for Turbo mode.

Short Duration Power Limit Override (1680)

Intel(R) Turbo Boost Technology will use this power limit for a very short duration. After that, the long duration power limit will be honored.


1/2/3/4 Core Ratio Limit (33/33/32/31)

These items show the Core Ratio limit value.

Press <Esc> to return to the M.I.B X menu page.

Chipset OverClocking Configuration

Scroll to this item to view the following screen:



Performance Memory Profiles (Automatic)

This item allows you to select the memory mode: Automatic, Manual, XMP Profile 1 or 2.

XMP Profile 1/2 (Supported/Not Supported)

These items show your motherboard supporting the XMP profile 1/2 or not.

CAS# Latency(tCL) (9)

This item determines the operation of DDR SDRAM memory CAS (column address strobe). It is recommended that you leave this item at the default value. The 2T setting requires faster memory that specifically supports this mode.

RAS# to CAS# Delay(tRCD) (9)

This item specifies RAS# to CAS# delay to Rd/Wr command to the same bank.

Row Precharge Time(tRP) (9)

This item specifies Row precharge to Active or Auto-Refresh of the same bank.

RAS# Active Time(tRAS) (24)

This item specifies the RAS# active time.

Write Recovery Time(tWR) (10)

This item specifies the write recovery time.

Row Refresh Cycle Time(tRFC) (74)

This item specifies the row refresh cycle time.

Active to Active Delay(tRRD) (4)

This item controls the active bank x to active bank y in memory clock cycles.

Write to Read Delay(tWTR) (5)

This item specifies the write to read delay time.

Read CAS# Precharge(tRTP) (5)

This item controls the Read to precharge delay for memory devices, in memory clock cycles.

Four Active Window Delay(tFAW) (20)

This item controls the four bank activate time in memory clock cycles.

Graphics Core Ratio Limit (20)

This item allows you to control the internal GFX Turbo ratio.

Graphics Voltage(1/256) (0)

This item allows you to adjust the internal GFX voltage.

Press <Esc> to return to the M.I.B X menu page.

B.O.M.P Technology (Enabled)

This item allows users to enable or disable B.O.M.P technology. This function can run safe setting to setup menu when system boot fail 3 times.

Auto Detect DIMM/PCI Clk (Enabled)

When this item is enabled, BIOS will disable the clock signal of free DIMM/PCI slots.

Spread Spectrum (Enabled)

If you enable spread spectrum, it can significantly reduce the EMI (Electro-Magnetic Interference) generated by the system.

CPU/AXG/IMC/DIMM/System Agent/PCH/CPU PLL Voltage (Auto)

These items allows you to adjust the CPU/AXG/IMC/DIMM/System Agent/PCH/CPU PLL voltage.

Processor Speed (1600 MHz)

This item shows the CPU speed.

Memory Frequency (1333 MHz)

This item shows the memory frequency.

Total Memory (4096 MB (DDR3))

This item shows the total memory.

CPU Current Voltage (0.960V)

This item shows the CPU current voltage.

**Warning:**

Over-clocking components can adversely affect the reliability of the system and introduce errors into your system. Over-clocking can permanently damage the motherboard by generating excess heat in components that are run beyond the rated limits.


Fail-Safe Procedures for Over-clocking

When end-users encounter failure after attempting over-clocking, please take the following steps to recover from it.

1. Shut down the computer.
2. Press and hold the "Page Up Key (PgUp)" of the keyboard, and then boot the PC up.
3. Two seconds after the PC boots up, release the "Page Up Key (PgUp)".
4. The BIOS returns to the default setting by itself.

Boot Menu

This page enables you to set the keyboard NumLock state.



Bootup NumLock State (On)


This item enables you to select NumLock state.

1st/2nd/3rd/4th/5th/6th/7th/8th Boot

These items show the boot priorities.

☒ Hard Disk Drive Priorities

Scroll to this item to view the following screen:




Hard Disk Drive Priorities

This item enables you to specify the sequence of loading the operating system from the installing hard disk drive.

Press <Esc> to return to the Boot Menu page.

CD/DVD ROM Drive Priorities

Scroll to this item to view the following screen:




CD/DVD ROM Drive Priorities

This item enables you to specify the sequence of loading the operating system from the installing CD/DVD ROM drive.

Press <Esc> to return to the Boot Menu page.

USB/IDE Floppy Drive Priorities

Scroll to this item to view the following screen:




USB/IDE Floppy Drive Priorities

This item enables you to specify the sequence of loading the operating system from the installing USB/IDE Floppy drive.

Press <Esc> to return to the Boot Menu page.

■ USB CD/DVD ROM Drive Priorities

Scroll to this item to view the following screen:




USB CD/DVD ROM Drive Priorities

This item enables you to specify the sequence of loading the operating system from the installing USB CD/DVD ROM drive.

Press <Esc> to return to the Boot Menu page.

■ USB HardDisk Drive Priorities

Scroll to this item to view the following screen:




USB HardDisk Drive Priorities

This item enables you to specify the sequence of loading the operating system from the installing USB HardDisk drive.

Press <Esc> to return to the Boot Menu page.

▣ USB Flash Drive Priorities

Scroll to this item to view the following screen:




USB Flash Drive Priorities

This item enables you to specify the sequence of loading the operating system from the installing USB Flash drive.

Press <Esc> to return to the Boot Menu page.

▣ NETWORK Device Priorities

Scroll to this item to view the following screen:



NETWORK Device Priorities

This item enables you to specify the sequence of loading the operating system from the installing network device.

Press <Esc> to return to the Boot Menu page.

■ UEFI Boot Drive Priorities

Scroll to this item to view the following screen:




UEFI Boot Drive Priorities

This item enables you to specify the sequence of loading the operating system from the installing UEFI Boot drive.

Press <Esc> to return to the Boot Menu page.

Security Menu

This page enables you to set setup administrator password and user password.



Administrator Password Status (Not Install)

This item shows administrator password installed or not.

User Password Status (Not Install)


This item shows user password installed or not.

Administrator Password

Press <Enter> to setup administrator password.


Exit Menu

This page enables you to exit system setup after saving or without saving the changes.



Profile Configuration

Scroll to this item to view the following screen:



Back to EZ Mode

This item enables you to back to EZ mode.

Save Changes and Exit

This item enables you to exit system setup after saving the changes.

Discard Changes and Exit

This item enables you to exit system setup without saving any changes.

Save Changes and Reset

This item enables you to reset the system setup after saving the changes.

Discard Changes and Reset

This item enables you to reset system setup without saving any changes.

Save Options

This item enables you to save the options that you have made.

Save Changes

This item enables you to save the changes that you have made.

Discard Changes

This item enables you to discard any changes that you have made.

Restore Defaults

This item enables you to restore the system defaults.

Boot Override

Use this item to select the boot device.

Updating the BIOS

You can download and install updated BIOS for this motherboard from the manufacturer's Website. New BIOS provides support for new peripherals, improvements in performance, or fixes for known bugs. Install new BIOS as follows:

- 1 If your motherboard has a BIOS protection jumper, change the setting to allow BIOS flashing.
- 2 If your motherboard has an item called Firmware Write Protect in Advanced BIOS features, disable it. (Firmware Write Protect prevents BIOS from being overwritten.)
- 3 Prepare a bootable device or create a bootable system disk. (Refer to Windows online help for information on creating a bootable system disk.)
- 4 Download the Flash Utility and new BIOS file from the manufacturer's Web site. Copy these files to the bootable device.
- 5 Turn off your computer and insert the bootable device in your computer. (You might need to run the Setup Utility and change the boot priority items on the Advanced BIOS Features Setup page, to force your computer to boot from the bootable device first.)
- 6 At the C:\ or A:\ prompt, type the Flash Utility program name and the file name of the new BIOS and then press <Enter>. Example: AFUDOS.EXE 040706.ROM
- 7 When the installation is complete, remove the bootable device from the computer and restart your computer. If your motherboard has a Flash BIOS jumper, reset the jumper to protect the newly installed BIOS from being overwritten. The computer will restart automatically.

This concludes Chapter 3. Refer to the next chapter for information on the software supplied with the motherboard.


Memo

Chapter 4

Using the Motherboard Software

Auto-installing under Windows XP/Vista/7


The auto-install DVD-ROM makes it easy for you to install the drivers and software. The support software DVD-ROM disc loads automatically under Windows XP/Vista/7. When you insert the DVD-ROM disc in the DVD-ROM drive, the auto-run feature will automatically bring up the installation screen. The screen has four buttons on it: **Setup**, **Utilities**, **Browse CD** and **Exit**.



Running Setup

Follow these instructions to install device drivers and software for the motherboard:


1. Click **Setup**. The installation program begins:



The following screens are examples only. The screens and driver lists will be different according to the motherboard you are installing.

The motherboard identification is located in the upper left-hand corner.

2. Click **Next**. The following screen appears:



3. Check the box next to the items you want to install. The default options are recommended.
4. Click **Next** to run the Installation Wizard. An item installation screen appears:




5. Follow the instructions on the screen to install the items.



Drivers and software are automatically installed in sequence. Follow the onscreen instructions, confirm commands and allow the computer to restart a few times to complete the installation.

Windows Vista/7 will appear below UAC (User Account Control) message after the system restart. You must select "Allow" to install the next driver. Continue this process to complete the drivers installation.



Manual Installation

If the auto-install DVD-ROM does not work on your system, you can still install drivers through the file manager for your OS (for example, Windows Explorer). Look for the chipset and motherboard model, and then browse to the directory and path to begin installing the drivers. Most drivers have a setup program (SETUP.EXE) that automatically detects your operating system before installation. Other drivers have the setup program located in the operating system subfolder.

If the driver you want to install does not have a setup program, browse to the operating system subfolder and locate the readme text file (README.TXT or README.DOC) for information on installing the driver or software for your operating system.

ECS Utility Software (Intelligent EZ Utility)

ECS Intelligent EZ Utility provides friendly interfaces under Windows O.S, which makes your computing more easily and conveniently.




These software(s) are subject to change at anytime without prior notice. Please refer to the support disk for available software.

eSF

eSF(Smart Fan) utility provides easy and safe way to adjust fan speed in accordance with your PC's system loading and temperature.

It has five modes to adjust fan speed in a safe range without entering the BIOS to optimize your system cooling environment.




eDLU

ECS eDLU utility makes updating drivers fast and easy. eDLU saves time and hassle by listing all the latest drivers online. Just select the one you prefer and start to download and install the drivers.



eBLU

ECS eBLU utility makes BIOS update faster and easier. eBLU will list the latest BIOS with a default check-mark. Click “install” button to install.



eOC

ECS eOC Utility is a simple over-clocking tool that provides user-friendly windows operation interface for novices and over-clockers. Combining with ECS MIB III technology, eOC challenges the undiscovered over-clocking capability than ever before.

Monitor




Easy Tuning



Advance Tuning



Options



Chapter 5

ATI CrossFire™ Technology Support

This motherboard supports the ATI CrossFire™ Technology that allows you to install multi-graphics processing units (GPU) graphics cards. Follow the installation procedures in this section.

Requirements

- 1 Two identical CrossFireX™ ready graphic cards are needed for the setup of 2-way CrossFireX™ configuration.
- 2 You would need one CrossfireX™ bridge cable.
- 3 Make sure that your graphics card driver supports the ATI CrossFireX™ technology. Download the latest driver from the ATI website (www.ati.com).
- 4 Make sure that your power supply unit (PSU) can provide at least the minimum power required by your system.

Installing CrossFireX™ graphics cards

1. Insert the CrossFireX™ graphics cards into the **PCIEX16X/PCIEX16X_S** slots. Make sure that the card is properly seated on the slot.

For 2-way configuration, install two graphic cards on PCIEX16X & PCIEX16X_S and connect them with the CrossFire™ Bridge.



** For reference only*

2. Connect the cable from your monitors to the CrossFireX™ ready graphics card installed on the **PCIE16X** slot.




** For reference only*

3. Connect an auxiliary power source from the power supply to the graphics cards.

The Catalyst™ Control Center Dialog Box

To enable CrossFireX™:

- Install ATI graphic card driver.
- Enter the Catalyst™ Control Center Dialog Box.
- check the “Enable CrossFireX™” item.
- Click OK to apply.



Memo

Chapter 6

NVIDIA® Hybrid SLI® Technology Support

This motherboard supports the NVIDIA® SLI® Technology that allows you to install multi-graphics processing units (GPU) graphics cards. Follow the installation procedures in this section.


Requirements

1. Two or three identical SLI® ready graphic cards are needed for the setup of 2-way SLI configuration.
2. Make sure that your graphics card driver supports the NVIDIA® SLI® technology.
3. Make sure that your power supply unit (PSU) can provide at least the minimum power required by your system.

Installing your NVIDIA® SLI-Ready Components


1. Install both of the NVIDIA® SLI-Ready graphics cards.

For 2-way configuration, install two graphic cards on PCIE16X & PCIE16X_S and connect them with one SLI bridge.



** For reference only*

2. Connect the cable from your monitors to the SLI-Ready graphics card installed on the **PCIe16X** slot.




** For reference only*

Once the new NVIDIA® SLI-certified components have been installed in the system, they will be recognized by the operating system upon Windows boot-up. A Found NewHardware message will be displayed:



Enabling NVIDIA® SLI

1. Click on the SLI capable system message to open the following window.



Description:


All NVIDIA® GPUs work together with SLI technology to increase the rendering performance of your 3D applications.

Typical usage scenarios:

- Playing 3D games
- Using any application that renders hardware-accelerated Direct 3D or OpenGL content.

2. Select the checkbox Enable SLI technology and then click Apply
You now have an NVIDIA® SLI-enabled PC!
You can also access these settings by opening the NVIDIA® Control Panel (right-click on desktop), clicking on 3D Settings (shown below) and then selecting “SetSLI configuration”.

Control Panel Setting of 2-Way SLI



All in all, the NVIDIA SLI technology works.

This concludes Chapter 6.

Chapter 7

Intel® Matrix Storage Manager RAID Configuration

The Intel® Matrix Storage Manager allows you to configure RAID 0, and 1 sets on the external Serial ATA hard disk drives.

Before creating a RAID set


Prepare the following items:

1. One SATA HDD.
2. A write-enabled floppy disk.
3. Microsoft® Windows® OS installation disk (Windows XP/Vista).
4. Motherboard support CD with Intel® Matrix Storage Manager driver.

Complete the following steps before you create a RAID set:

1. Install the external Serial ATA hard disk drive (HDD) on your system.
2. Set the *Onboard SATA Mode* item in the BIOS to *RAID*...


See section “Integrated Peripherals” for details.




3. Enter the Intel® Matrix Storage Manager option to set up your RAID configuration.
4. Create an Intel® Matrix Storage Manager driver disk for Windows® OS installation. See section “Creating a RAID driver disk” for details.
5. Install the Intel® Matrix Storage Manager driver after the Windows® OS had been installed.

Entering Intel® Matrix Storage Manager RAID BIOS utility

1. During POST, press <Ctrl-I> to enter the Intel® Matrix Storage Manager RAID BIOS menu.



2. The main Intel® Matrix Storage Manager RAID BIOS menu appears.
3. Use the arrow keys to move the color bar and navigate through the items.



Creating a RAID set

1. In the main Intel® Matrix Storage Manager RAID BIOS menu, highlight *Create RAID Volume* using the up/down arrow key then press <Enter>.



2. When the *RAID Level* item is highlighted, use the up/down arrow key to select the RAID set that you want to create.




When more than two HDDs are installed in your computer, the *Disks* item will be selectable. Then users can select the HDD that you want to belong to the RAID set. Please be noticed that selecting a wrong disk will result in losing the original data of the HDD.



3. Key in the RAID volume capacity. Use the up/down arrow to choose the *Capacity*. The default value indicates the maximum capacity using the selected disks. Entering a lower capacity allows you to create a second volume on these disks.




- When done, press <Enter> to confirm the creation of the RAID set. A dialogue box appears to confirm the action. Press <Y> to confirm; otherwise, press <N>.




Pressing <Y> deletes all the data in the HDDs.

- The following screen appears, displaying the relevant information about the RAID set you created.




Users please be noted that RAID 0 (Stripe) is set to accelerate the data access, and RAID 1 (Mirror) is set to provide the data backup. If you want to set RAID 0, you need to set the *2nd Boot Device* item in the BIOS to *Intel Volume0*. See section “Advanced Setup” for details.




Deleting a RAID set

1. In the main Intel® Matrix Storage Manager RAID BIOS menu, highlight *Delete RAID Volume* using the up/down arrow key then press <Enter>.



2. Use the space bar to select the RAID set you want to delete.
Press the key to delete the set.
3. A dialogue box appears to confirm the action. Press <Y> to confirm; otherwise, press <N>.



Pressing <Y> deletes all the data in the HDDs.


Resetting disks to Non-RAID



An HDD that has been previously configured as part of another RAID set in another platform is called a broken RAID HDD. When you install a broken RAID HDD, you cannot select this disk when configuring a RAID set through the Intel® Matrix Storage Manager option. If you still want to use this broken RAID HDD as part of the RAID set configured through the Intel® Matrix Storage Manager, you may do so by resetting the disk to Non-RAID. You will, however, lose all data and previous RAID configurations.

To reset disks to Non-RAID:

1. In the main Intel® Matrix Storage Manager RAID BIOS menu, highlight *Reset Disks to Non-RAID* using the up/down arrow key then press <Enter>.



2. Use the space bar to select the HDD to reset to Non-RAID.
3. A dialogue box appears to confirm the action. Press <Y> to confirm; otherwise, press <N>.

Pressing <Y> deletes all the data in the HDDs.

Exiting Setup

When you have finished, highlight *Exit* using the up/down arrow key then press <Enter> to exit the Intel® Matrix Storage Manager RAID BIOS utility.

A dialogue box appears to confirm the action. Press <Y> to confirm; otherwise, press <N> to return to the Intel® Matrix Storage Manager RAID BIOS menu.

Chapter 8

Trouble Shooting

Start up problems during assembly

After assembling the PC for the first time you may experience some start up problems. Before calling for technical support or returning for warranty, this chapter may help to address some of the common questions using some basic troubleshooting tips. You may also log onto our ECS website for more information:

http://www.ecs.com.tw/ECSWebSite/Support/Support_FAQ.aspx?MenuID=49&childid=M_49&lanID=0

a) System does not power up and the fans are not running.

1. Disassemble the PC to remove the VGA adaptor card, DDR memory, LAN, USB and other peripherals including keyboard and mouse. Leave only the motherboard, CPU with CPU cooler and power supply connected. Make sure the power cord is plugged into the wall socket & the switch on the Power Supply Unit (PSU) is turned " on " as well. Turn on again to see if the CPU and power supply fans are running.
2. Make sure to remove any unused screws or other metal objects such as screwdrivers from the inside PC case. This is to prevent damage from short circuit.
3. Check the CPU FAN connector is connected to the motherboard.
4. For Intel platforms check the pins on the CPU socket for damage or bent. A bent pin may cause failure to boot and sometimes permanent damage from short circuit.
5. Check the 12V power connector is connected to the motherboard.
6. Check that the 12V power & ATX connectors are fully inserted into the motherboard connectors. Make sure the latches of the cable and connector are locked into place.

b) Power is on, fans are running but there is no display

1. Make sure the monitor is turned on and the monitor cable is properly connected to the PC.
2. Check the VGA adapter card (if applicable) is inserted properly.
3. Listen for beep sounds. If you are using internal PC speaker make sure it is connected.
 - a. continuous 3 short beeps: memory not detected
 - b. 1 long beep and 8 short beeps: VGA not detected

c) The PC suddenly shuts down while booting up.

1. The CPU may experience overheating so it will shutdown to protect itself. Apply the thermal grease onto the CPU heatsink & ensure the CPU fan is well-connected with the CPU heatsink. Check if the CPU fan is working properly while the system is running.

2. From the BIOS setting, try to disable the Smartfan function to let the fan run at default speed. Doing a Load Optimised Default will also disable the Smartfan.

Start up problems after prolong use

After a prolong period of use your PC may experience start up problems again. This may be caused by breakdown of devices connected to the motherboard such as HDD, CPU fan, etc. The following tips may help to revive the PC or identify the cause of failure.

1. Clear the CMOS values using the CLR_CMOS jumper. Refer to CLR_CMOS jumper in Chapter 2 for Checking Jumper Settings in this user manual. When completed, follow up with a Load Optimised Default in the BIOS setup.
2. Check the CPU cooler fan for dust. Long term accumulation of dust will reduce its effectiveness to cool the processor. Clean the cooler or replace a new one if necessary.
3. Check that the 12V power & ATX connectors are fully inserted into the motherboard connectors. Make sure the latches of the cable and connector are locked into place.
4. Remove the hard drive, optical drive or DDR memory to determine which of these components may be at fault.
5. Check whether there is any bulked up electrolytic capacitor or abnormal component.


Please logo onto our ECS website: http://www.ecs.com.tw/ECSWebSite/Support/Technical_Support_List.aspx?MenuID=50&LanID=0 for more information.

Maintenance and care tips

Your computer, like any electrical appliance, requires proper care and maintenance. Here are some basic PC care tips to help prolong the life of the motherboard and keep it running as best as it can.

1. Keep your computer in a well ventilated area. Leave some space between the PC and the wall for sufficient airflow.
2. Keep your computer in a cool dry place. Avoid dusty areas, direct sunlight and areas of high moisture content.
3. Routinely clean the CPU cooler fan to remove dust and hair.
4. In places of hot and humid weather you should turn on your computer once every other week to circulate the air and prevent damage from humidity.
5. Add more memory to your computer if possible. This not only speeds up the system but also reduces the loading of your hard drive to prolong its life span.
6. If possible, ensure the power cord has an earth ground pin directly from the wall outlet. This will reduce voltage fluctuation that may damage sensitive devices.

Basic Troubleshooting Flowchart



Memo

POST Code Checkpoints

The POST code checkpoints are the largest set of checkpoints during the BIOS pre-boot process. The following table describes the type of checkpoints that may occur during the POST portion of the BIOS :

Checkpoint	Description
01-0F	SEC Status Codes & Errors
10-2F	PEI execution up to and including memory detection
30-4F	PEI execution after memory detection
50-5F	PEI errors
60-CF	DXE execution up to BDS
D0-DF	DXE errors
E0-E8	S3 Resume (PEI)
E9-EF	S3 Resume errors (PEI)
F0-F8	Recovery (PEI)
F9-FF	Recovery errors (PEI)
0	Not used
1	Power on. Reset type detection (soft/hard).
2	AP initialization before microcode loading
3	North Bridge initialization before microcode loading
4	South Bridge initialization before microcode loading
5	OEM initialization before microcode loading
6	Microcode loading
7	AP initialization after microcode loading
8	North Bridge initialization after microcode loading
9	South Bridge initialization after microcode loading
A	OEM initialization after microcode loading
B	Cache initialization
C-D	Reserved for future AMI SEC error codes
E	Microcode not found
F	Microcode not loaded
10	PEI Core is started
11	Pre-memory CPU initialization is started
12	Pre-memory CPU initialization (CPU module specific)
13	Pre-memory CPU initialization (CPU module specific)
14	Pre-memory CPU initialization (CPU module specific)
15	Pre-memory North Bridge initialization is started
16	Pre-Memory North Bridge initialization (North Bridge module specific)
17	Pre-Memory North Bridge initialization (North Bridge module specific)
18	Pre-Memory North Bridge initialization (North Bridge module specific)
19	Pre-memory South Bridge initialization is started
1A	Pre-memory South Bridge initialization (South Bridge module specific)
1B	Pre-memory South Bridge initialization (South Bridge module specific)
1C	Pre-memory South Bridge initialization (South Bridge module specific)
1D-2A	OEM pre-memory initialization codes
2B	Memory initialization. Serial Presence Detect (SPD) data reading
2C	Memory initialization. Memory presence detection
2D	Memory initialization. Programming memory timing information
2E	Memory initialization. Configuring memory
2F	Memory initialization (other).
30	Reserved for ASL (see ASL Status Codes section below)
31	Memory Installed
32	CPU post-memory initialization is started
33	CPU post-memory initialization. Cache initialization
34	CPU post-memory initialization. Application Processor(s) (AP) initialization

35	CPU post-memory initialization. Boot Strap Processor (BSP) selection
36	CPU post-memory initialization. System Management Mode (SMM) initialization
37	Post-Memory North Bridge initialization is started
38	Post-Memory North Bridge initialization (North Bridge module specific)
39	Post-Memory North Bridge initialization (North Bridge module specific)
3A	Post-Memory North Bridge initialization (North Bridge module specific)
3B	Post-Memory South Bridge initialization is started
3C	Post-Memory South Bridge initialization (South Bridge module specific)
3D	Post-Memory South Bridge initialization (South Bridge module specific)
3E	Post-Memory South Bridge initialization (South Bridge module specific)
3F-4E	OEM post memory initialization codes
4F	DXE IPL is started
50	Memory initialization error. Invalid memory type or incompatible memory speed
51	Memory initialization error. SPD reading has failed
52	Memory initialization error. Invalid memory size or memory modules do not match.
53	Memory initialization error. No usable memory detected
54	Unspecified memory initialization error.
55	Memory not installed
56	Invalid CPU type or Speed
57	CPU mismatch
58	CPU self test failed or possible CPU cache error
59	CPU micro-code is not found or micro-code update is failed
5A	Internal CPU error
5B	reset PPI is not available
5C-5F	Reserved for future AML error codes
E0	S3 Resume is started (S3 Resume PPI is called by the DXE IPL)
E1	S3 Boot Script execution
E2	Video repost
E3	OS S3 wake vector call
E4-E7	Reserved for future AML progress codes
E0	S3 Resume is started (S3 Resume PPI is called by the DXE IPL)
E8	S3 Resume Failed in PEI
E9	S3 Resume PPI not Found
EA	S3 Resume Boot Script Error
EB	S3 OS Wake Error
EC-EF	Reserved for future AML error codes
F0	Recovery condition triggered by firmware (Auto recovery)
F1	Recovery condition triggered by user (Forced recovery)
F2	Recovery process started
F3	Recovery firmware image is found
F4	Recovery firmware image is loaded
F5-F7	Reserved for future AML progress codes
F0	Recovery condition triggered by firmware (Auto recovery)
F1	Recovery condition triggered by user (Forced recovery)
F2	Recovery process started
F3	Recovery firmware image is found
F4	Recovery firmware image is loaded
F5-F7	Reserved for future AML progress codes
F8	Recovery PPI is not available
F9	Recovery capsule is not found
FA	Invalid recovery capsule

FB-FF	Reserved for future AMI error codes
1	Memory not Installed
1	Memory was installed twice (InstallPeiMemory routine in PEI Core called twice)
2	Recovery started
3	DXE IPL was not found
3	DXE Core Firmware Volume was not found
7	Reset PPI is not available
4	Recovery failed
4	S3 Resume failed
60	DXE Core is started
61	NVRAM initialization
62	Installation of the South Bridge Runtime Services
63	CPU DXE initialization is started
64	CPU DXE initialization (CPU module specific)
65	CPU DXE initialization (CPU module specific)
66	CPU DXE initialization (CPU module specific)
67	CPU DXE initialization (CPU module specific)
68	PCI host bridge initialization
69	North Bridge DXE initialization is started
6A	North Bridge DXE SMM initialization is started
6B	North Bridge DXE initialization (North Bridge module specific)
6C	North Bridge DXE initialization (North Bridge module specific)
6D	North Bridge DXE initialization (North Bridge module specific)
6E	North Bridge DXE initialization (North Bridge module specific)
6F	North Bridge DXE initialization (North Bridge module specific)
70	South Bridge DXE initialization is started
71	South Bridge DXE SMM initialization is started
72	South Bridge devices initialization
73	South Bridge DXE Initialization (South Bridge module specific)
74	South Bridge DXE Initialization (South Bridge module specific)
75	South Bridge DXE Initialization (South Bridge module specific)
76	South Bridge DXE Initialization (South Bridge module specific)
77	South Bridge DXE Initialization (South Bridge module specific)
78	ACPI module initialization
79	CSM initialization
7A-7F	Reserved for future AMI DXE codes
80-8F	OEM DXE initialization codes
90	Boot Device Selection (BDS) phase is started
91	Driver connecting is started
92	PCI Bus initialization is started
93	PCI Bus Hot Plug Controller Initialization
94	PCI Bus Enumeration
95	PCI Bus Request Resources
96	PCI Bus Assign Resources
97	Console Output devices connect
98	Console input devices connect
99	Super IO Initialization
9A	USB initialization is started
9B	USB Reset
9C	USB Detect
9D	USB Enable

9E-9F	Reserved for future AMI codes
A0	IDE initialization is started
A1	IDE Reset
A2	IDE Detect
A3	IDE Enable
A4	SCSI initialization is started
A5	SCSI Reset
A6	SCSI Detect
A7	SCSI Enable
A8	Setup Verifying Password
A9	Start of Setup
AA	Reserved for ASL (see ASL Status Codes section below)
AB	Setup Input Wait
AC	Reserved for ASL (see ASL Status Codes section below)
AD	Ready To Boot event
AE	Legacy Boot event
AF	Exit Boot Services event
B0	Runtime Set Virtual Address MAP Begin
B1	Runtime Set Virtual Address MAP End
B2	Legacy Option ROM Initialization
B3	System Reset
B4	USB hot plug
B5	PCI bus hot plug
B6	Clean-up of NVRAM
B7	Configuration Reset (reset of NVRAM settings)
B8-BF	Reserved for future AMI codes
C0-CF	OEM BDS initialization codes
D0	CPU initialization error
D1	North Bridge initialization error
D2	South Bridge initialization error
D3	Some of the Architectural Protocols are not available
D4	PCI resource allocation error. Out of Resources
D5	No Space for Legacy Option ROM
D6	No Console Output Devices are found
D7	No Console Input Devices are found
D8	Invalid password
D9	Error loading Boot Option (LoadImage returned error)
DA	Boot Option is failed (StartImage returned error)
DB	Flash update is failed
DC	Reset protocol is not available
4	Some of the Architectural Protocols are not available
5	No Console Output Devices are found
5	No Console Input Devices are found
1	Invalid password
6	Flash update is failed
7	Reset protocol is not available
8	Platform PCI resource requirements cannot be met
01	System is entering S1 sleep state
02	System is entering S2 sleep state
03	System is entering S3 sleep state
04	System is entering S4 sleep state